



***msi***<sup>™</sup>

**Z68A-GD65 (B3)  
Z68A-GD55 (B3)  
series**

MS-7681 (v4.x) Mainboard

## Copyright Notice

The material in this document is the intellectual property of **MICRO-STAR INTERNATIONAL**. We take every care in the preparation of this document, but no guarantee is given as to the correctness of its contents. Our products are under continual improvement and we reserve the right to make changes without notice.

## Trademarks

All trademarks in this manual are properties of their respective owners.

- MSI® is registered trademark of Micro-Star Int'l Co.,Ltd.
- NVIDIA® is registered trademark of NVIDIA Corporation.
- ATI® is registered trademark of AMD Corporation.
- AMD® is registered trademarks of AMD Corporation.
- Intel® is registered trademarks of Intel Corporation.
- Windows® is registered trademarks of Microsoft Corporation.
- AMI® is registered trademark of American Megatrends Inc.
- Award® is a registered trademark of Phoenix Technologies Ltd.
- Sound Blaster® is registered trademark of Creative Technology Ltd.
- Realtek® is registered trademark of Realtek Semiconductor Corporation.
- JMicon® is registered trademark of JMicon Technology Corporation.
- Netware® is registered trademark of Novell, Inc.
- Lucid® is trademark of LucidLogix Technologies, Ltd.
- VIA® is registered trademark of VIA Technologies, Inc.
- ASMedia® is registered trademark of ASMedia Technology Inc.
- iPad, iPhone, and iPod are trademarks of Apple Inc.

## Revision History

Revision	Revision History	Date
V4.0	First release	2011/05

## Technical Support

If a problem arises with your system and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please try the following help resources for further guidance.

- ☐ Visit the MSI website for technical guide, BIOS updates, driver updates, and other information: <http://www.msi.com/service/download>
- ☐ Contact our technical staff at: <http://support.msi.com>

## Safety Instructions

- Always read the safety instructions carefully.
- Keep this User's Manual for future reference.
- Keep this equipment away from humidity.
- Lay this equipment on a reliable flat surface before setting it up.
- The openings on the enclosure are for air convection hence protects the equipment from overheating. **DO NOT COVER THE OPENINGS.**
- Make sure the voltage of the power source is at 110/220V before connecting the equipment to the power inlet.
- Place the power cord such a way that people can not step on it. Do not place anything over the power cord.
- Always Unplug the Power Cord before inserting any add-on card or module.
- All cautions and warnings on the equipment should be noted.
- Never pour any liquid into the opening that can cause damage or cause electrical shock.
- If any of the following situations arises, get the equipment checked by service personnel:
  - The power cord or plug is damaged.
  - Liquid has penetrated into the equipment.
  - The equipment has been exposed to moisture.
  - The equipment does not work well or you can not get it work according to User's Manual.
  - The equipment has been dropped and damaged.
  - The equipment has obvious sign of breakage.

**DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT ABOVE 60°C (140°F), IT MAY DAMAGE THE EQUIPMENT.**

**CAUTION:** There is a risk of explosion, if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer.

**警告使用者:**

這是甲類資訊產品，在居住的環境中使用時，可能會造成無線電干擾，在這種情況下，使用者會被要求採取某些適當的對策。



**廢電池請回收**

For better environmental protection, waste batteries should be collected separately for recycling special disposal.

## FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below.



- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.


### Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### Notice 2

Shielded interface cables and A.C. power cord, if any, must be used in order to comply with the emission limits.

VOIR LA NOTICE D'INSTALLATION AVANT DE RACCORDER AU RESEAU.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

## WEEE (Waste Electrical and Electronic Equipment) Statement

### ENGLISH

To protect the global environment and as an environmentalist, MSI must remind you that...



Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2002/96/EC, which takes effect on August 13, 2005, products of "electrical and electronic equipment" cannot be discarded as municipal wastes anymore, and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life. MSI will comply with the product take back requirements at the end of life of MSI-branded products that are sold into the EU. You can return these products to local collection points.

### DEUTSCH

Hinweis von MSI zur Erhaltung und Schutz unserer Umwelt

Gemäß der Richtlinie 2002/96/EG über Elektro- und Elektronik-Altgeräte dürfen Elektro- und Elektronik-Altgeräte nicht mehr als kommunale Abfälle entsorgt werden. MSI hat europaweit verschiedene Sammel- und Recyclingunternehmen beauftragt, die in die Europäische Union in Verkehr gebrachten Produkte, am Ende seines Lebenszyklus zurückzunehmen. Bitte entsorgen Sie dieses Produkt zum gegebenen Zeitpunkt ausschliesslich an einer lokalen Altgerätesammelstelle in Ihrer Nähe.

### FRANÇAIS

En tant qu'écologiste et afin de protéger l'environnement, MSI tient à rappeler ceci...

Au sujet de la directive européenne (EU) relative aux déchets des équipement électriques et électroniques, directive 2002/96/EC, prenant effet le 13 août 2005, que les produits électriques et électroniques ne peuvent être déposés dans les décharges ou tout simplement mis à la poubelle. Les fabricants de ces équipements seront obligés de récupérer certains produits en fin de vie. MSI prendra en compte cette exigence relative au retour des produits en fin de vie au sein de la communauté européenne. Par conséquent vous pouvez retourner localement ces matériels dans les points de collecte.

### РУССКИЙ

Компания MSI предпринимает активные действия по защите окружающей среды, поэтому напоминаем вам, что...

В соответствии с директивой Европейского Союза (ЕС) по предотвращению загрязнения окружающей среды использованным электрическим и электронным оборудованием (директива WEEE 2002/96/EC), вступающей в силу 13 августа 2005 года, изделия, относящиеся к электрическому и электронному оборудованию, не могут рассматриваться как бытовой мусор, поэтому производители вышеперечисленного электронного оборудования обязаны принимать его для переработки по окончании срока службы. MSI обязуется соблюдать требования по приему продукции, проданной под маркой MSI на территории ЕС, в переработку по окончании срока службы. Вы можете вернуть эти изделия в специализированные пункты приема.

## ESPAÑOL

MSI como empresa comprometida con la protección del medio ambiente, recomienda: Bajo la directiva 2002/96/EC de la Unión Europea en materia de desechos y/o equipos electrónicos, con fecha de rigor desde el 13 de agosto de 2005, los productos clasificados como "eléctricos y equipos electrónicos" no pueden ser depositados en los contenedores habituales de su municipio, los fabricantes de equipos electrónicos, están obligados a hacerse cargo de dichos productos al termino de su período de vida. MSI estará comprometido con los términos de recogida de sus productos vendidos en la Unión Europea al final de su periodo de vida. Usted debe depositar estos productos en el punto limpio establecido por el ayuntamiento de su localidad o entregar a una empresa autorizada para la recogida de estos residuos.

## NEDERLANDS

Om het milieu te beschermen, wil MSI u eraan herinneren dat....

De richtlijn van de Europese Unie (EU) met betrekking tot Vervuiling van Electrische en Electronische producten (2002/96/EC), die op 13 Augustus 2005 in zal gaan kunnen niet meer beschouwd worden als vervuiling. Fabrikanten van dit soort producten worden verplicht om producten retour te nemen aan het eind van hun levenscyclus. MSI zal overeenkomstig de richtlijn handelen voor de producten die de merknaam MSI dragen en verkocht zijn in de EU. Deze goederen kunnen geretourneerd worden op lokale inzamelingspunten.

## SRPSKI

Da bi zaštitili prirodnu sredinu, i kao preduzeće koje vodi računa o okolini i prirodnoj sredini, MSI mora da vas podesti da...

Po Direktivi Evropske unije ("EU") o odbačenju eelektronskoj i električnoj opremi, Direktiva 2002/96/EC, koja stupa na snagu od 13. Avgusta 2005, proizvodi koji spadaju pod "elektronsku i električnu opremu" ne mogu više biti odbačeni kao običan otpad i proizvođači ove opreme biće prinuđeni da uzmu natrag ove proizvode na kraju njihovog uobičajenog veka trajanja. MSI će poštovati zahtev o preuzimanju ovakvih proizvoda kojima je istekao vek trajanja, koji imaju MSI oznaku i koji su prodati u EU. Ove proizvode možete vratiti na lokalnim mestima za prikupljanje.

## POLSKI

Aby chronić nasze środowisko naturalne oraz jako firma dbająca o ekologię, MSI przypomina, że...

Zgodnie z Dyrektywą Unii Europejskiej ("UE") dotyczącą odpadów produktów elektrycznych i elektronicznych (Dyrektywa 2002/96/EC), która wchodzi w życie 13 sierpnia 2005, tzw. "produkty oraz wyposażenie elektryczne i elektroniczne" nie mogą być traktowane jako śmieci komunalne, tak więc producenci tych produktów będą zobowiązani do odbierania ich w momencie gdy produkt jest wycofywany z użycia. MSI wypełni wymagania UE, przyjmując produkty (sprzedawane na terenie Unii Europejskiej) wycofywane z użycia. Produkty MSI będzie można zwracać w wyznaczonych punktach zbiorczych.

## TÜRKÇE

Çevreci özelliğiyle bilinen MSI dünyada çevreyi korumak için hatırlatır:

Avrupa Birliği (AB) Kararnamesi Elektrik ve Elektronik Malzeme Atığı, 2002/96/EC Kararnamesi altında 13 Ağustos 2005 tarihinden itibaren geçerli olmak üzere, elektrikli ve elektronik malzemeler diğer atıklar gibi çöpe atılamayacak ve bu elektronik cihazların üreticileri, cihazların kullanım süreleri bittikten sonra ürünleri geri toplamakla yükümlü olacaktır. Avrupa Birliği'ne satılan MSI markalı ürünlerin kullanım süreleri bittiğinde MSI ürünlerin geri alınması isteği ile işbirliği içerisinde olacaktır. Ürünlerinizi yerel toplama noktalarına bırakabilirsiniz.

## ČESKY

Záleží nám na ochraně životního prostředí - společnost MSI upozorňuje...

Podle směrnice Evropské unie ("EU") o likvidaci elektrických a elektronických výrobků 2002/96/EC platné od 13. srpna 2005 je zakázáno likvidovat "elektrické a elektronické výrobky" v běžném komunálním odpadu a výrobci elektrických výrobků, na které se tato směrnice vztahuje, budou povinni odebírat takové výrobky zpět po skončení jejich životnosti. Společnost MSI splní požadavky na odebírání výrobků značky MSI, prodávaných v zemích EU, po skončení jejich životnosti. Tyto výrobky můžete odevzdat v místních sběrnách.

## MAGYAR

Annak érdekében, hogy környezetünket megvédjük, illetve környezetvédként fellépve az MSI emlékezteti Önt, hogy ...

Az Európai Unió („EU”) 2005. augusztus 13-án hatályba lépő, az elektromos és elektronikus berendezések hulladékairól szóló 2002/96/EK irányelve szerint az elektromos és elektronikus berendezések többé nem kezelhetőek lakossági hulladékként, és az ilyen elektronikus berendezések gyártói kötelessé válnak az ilyen termékek visszavételére azok hasznos élettartama végén. Az MSI betartja a termékvisszavétellel kapcsolatos követelményeket az MSI márkanév alatt az EU-n belül értékesített termékek esetében, azok élettartamának végén. Az ilyen termékeket a legközelebbi gyűjtőhelyre viheti.

## ITALIANO

Per proteggere l'ambiente, MSI, da sempre amica della natura, ti ricorda che....

In base alla Direttiva dell'Unione Europea (EU) sullo Smaltimento dei Materiali Elettrici ed Elettronici, Direttiva 2002/96/EC in vigore dal 13 Agosto 2005, prodotti appartenenti alla categoria dei Materiali Elettrici ed Elettronici non possono più essere eliminati come rifiuti municipali: i produttori di detti materiali saranno obbligati a ritirare ogni prodotto alla fine del suo ciclo di vita. MSI si adegnerà a tale Direttiva ritirando tutti i prodotti marchiati MSI che sono stati venduti all'interno dell'Unione Europea alla fine del loro ciclo di vita. È possibile portare i prodotti nel più vicino punto di raccolta

# CONTENTS

Copyright Notice ..... ii

Trademarks ..... ii

Revision History..... ii

Technical Support..... ii

Safety Instructions.....iii

FCC-B Radio Frequency Interference Statement..... iv

WEEE (Waste Electrical and Electronic Equipment) Statement ..... v

**Chapter 1 Getting Started.....1-1**

    Mainboard Specifications ..... 1-2

    Mainboard Layout ..... 1-4

    Packing Contents ..... 1-5

    Optional Accessories ..... 1-5

**Chapter 2 Hardware Setup.....2-1**

    Quick Components Guide ..... 2-2

    Screw Holes ..... 2-3

    CPU (Central Processing Unit) ..... 2-4

    Memory ..... 2-7

    Power Supply ..... 2-9

    Back Panel..... 2-10

    Connectors..... 2-12

    Buttons ..... 2-18

    Voltage Check Point..... 2-19

    LED Status Indicators ..... 2-20

    Jumper ..... 2-21

    Slots ..... 2-22

**Chapter 3 BIOS Setup.....3-1**

    Entering Setup ..... 3-2

    The Main Menu ..... 3-4

    Green Power ..... 3-5

    Utilities..... 3-6

    Overclocking ..... 3-7


    Games..... 3-14

    Settings ..... 3-15



<b>Appendix A Realtek Audio</b> .....	<b>A-1</b>
Installing the Realtek HD Audio Driver.....	A-2
Software Configuration.....	A-3
Hardware Default Setting.....	A-5
<b>Appendix B Intel RAID</b> .....	<b>B-1</b>
Introduction .....	B-2
Using Intel Rapid Storage Technology Option ROM.....	B-3
Installing Driver .....	B-10
Degraded RAID Array .....	B-12
System Acceleration .....	B-14
RST Synchronization .....	B-16





## Chapter 1

# Getting Started

Thank you for choosing the **Z68A-GD65 (B3)/ Z68A-GD55 (B3)** Series (MS-7681 v4.X) ATX mainboard. The **Z68A-GD65 (B3)/ Z68A-GD55 (B3)** Series mainboards are based on **Intel® Z68 (B3)** chipsets for optimal system efficiency. Designed to fit the advanced **Intel® LGA1155** processor, the **Z68A-GD65 (B3)/ Z68A-GD55 (B3)** Series deliver a high performance and professional desktop platform solution.

## Mainboard Specifications

---

### Processor Support

- Intel® Core™ i7/ Core™ i5 /Core™ i3/ Pentium®/ Celeron® processor in the LGA1155 package  
(For the latest information about CPU, please visit <http://www.msi.com/service/cpu-support>)

### Chipset

- Intel® Z68 (B3) chipset

### Memory Support

- 4 DDR3 DIMMs support DDR3 2133(OC)/ 1600(OC)/ 1333/ 1066 DRAM (32GB Max)
- Supports Dual-Channel mode  
(For more information on compatible components, please visit <http://www.msi.com/service/test-report>)

### LAN

- Supports Gb LAN (10/100/1000) by Realtek® RTL8111E

### Audio

- Chip integrated by Realtek® ALC892
- Flexible 8-channel audio with jack sensing
- Compliant with Azalia 1.0 Spec

### SATA

- 4 SATA 6Gb/s ports
  - (SATA1~2) by Intel® Z68
  - (SATA7~8) by Marvell® 9128 (Z68A-GD65)
- 4 SATA 3Gb/s ports (SATA3~6) by Intel® Z68

### RAID

- SATA1~6 support Intel® Rapid Storage Technology (AHCI/ RAID 0/ 1/ 5/ 10) by Intel® Z68, support SSD caching for system acceleration
- SATA7~8 support RAID 0/ 1 mode by Marvell® SE9128

### USB 3.0

- 2 USB 3.0 ports and 1 USB 3.0 onboard connector by NEC D720200

### BIOS

- Supports Dual BIOS (Z68A-GD65)
- Supports Single BIOS (Z68A-GD55)

### Multi-GPU

- Supports ATI® CrossFireX™ Technology
- Supports NVIDIA® SLI™ Technology
- Supports Lucid® VIRTU Technology

## Connectors

- Back panel
  - 1 PS/2 keyboard/ mouse port
  - 1 Clear CMOS button
  - 1 Coaxial S/PDIF-Out port
  - 1 Optical S/PDIF-Out port
  - 4 USB 2.0 ports
  - 1 HDMI port\*\*
  - 1 VGA port\*\*
  - 1 DVI-D port\*\*
  - 1 LAN port
  - 2 USB 3.0 ports
  - 6 flexible audio ports
- \*\* (The VGA, DVI-D & HDMI ports only work with Integrated Graphics Processor)
- On-Board
  - 3 USB 2.0 connectors
  - 1 USB 3.0 connector
  - 1 Chassis Intrusion connector
  - 1 S/PDIF-Out connector
  - 1 Front Panel Audio connector
  - 1 TPM Module connector
  - 1 Serial connector
  - 1 set voltage check point
  - 1 DLED3 connector (optional)
  - 1 OC Genie button
  - 1 Power button
  - 1 Reset button

## Slots

- 2 PCIE x16 slots
- 3 PCIE x1 slots
- 2 PCI slots, support 3.3V/ 5V PCI bus Interface


## Form Factor

- ATX (30.5 cm X 24.5 cm)

## Mounting

- 9 mounting holes

# Mainboard Layout



**Z68A-GD65 (B3)/ Z68A-GD55 (B3) Series (MS-7681 v4.X)**  
**ATX Mainboard**

## Packing Contents



Mainboard

Driver / Utility  
DVD

User Guide



Back IO Shield



SATA Cable

## Optional Accessories

USB 2.0  
BracketUSB 3.0  
BracketS/PDIF Out  
BracketeSATA  
BracketV-Check  
Cable

M-Connector

USB3 to USB2  
ConnectorSATA Power  
CableCrossFire  
Cable

SLI Cable

eSATA Power  
Cable


\* These pictures are for reference only and may vary without notice.

\* The packing contents may vary according to the model you purchased.

\* If you need to purchase the optional accessories, please visit <http://www.msi.com/index.php> to inquire the part numbers or consult the dealer.








## Chapter 2

# Hardware Setup

This chapter provides you with the information about hardware setup procedures. While performing the installation, be careful in holding the components and following the installation procedures. For some components, if you install in the wrong orientation, the components will not work properly.


Use a grounded wrist strap before handling computer components. Static electricity may damage the components.

# Quick Components Guide



## Screw Holes

When you install the mainboard, you have to place the mainboard into the chassis in the correct direction. The locations of screws holes on the mainboard are shown as below.



Refer above picture to install standoffs in the appropriate locations on chassis and then screw through the mainboard screw holes into the standoffs.

### **Important**

- To prevent damage to the mainboard, any contact between the mainboard circuit and chassis or unnecessary standoffs mounted on the chassis is prohibited.
- Please make sure there are no metal components placed on the mainboard or within the chassis that may cause short circuit of the mainboard.

## CPU (Central Processing Unit)

When you are installing the CPU, make sure to install the cooler to prevent overheating. If you do not have the CPU cooler, consult your dealer before turning on the computer. For the latest information about CPU, please visit <http://www.msi.com/service/cpu-support>

### **Important**

#### **Overheating**

*Overheating will seriously damage the CPU and system. Always make sure the cooling fan can work properly to protect the CPU from overheating. Make sure that you apply an even layer of thermal paste (or thermal tape) between the CPU and the heatsink to enhance heat dissipation.*

#### **Replacing the CPU**


*While replacing the CPU, always turn off the ATX power supply or unplug the power supply's power cord from the grounded outlet first to ensure the safety of CPU.*

#### **Overclocking**

*This mainboard is designed to support overclocking. However, please make sure your components are able to tolerate such abnormal setting, while doing overclocking. Any attempt to operate beyond product specifications is not recommended. We do not guarantee the damages or risks caused by inadequate operation or beyond product specifications.*

### **Introduction to LGA 1155 CPU**

The surface of LGA 1155 CPU. Remember to apply some thermal paste on it for better heat dispersion.





## CPU & Cooler Installation



When you are installing the CPU, make sure the CPU has a cooler attached on the top to prevent overheating. Meanwhile, do not forget to apply some thermal paste on CPU before installing the heat sink/cooler fan for better heat dispersion.

Follow the steps below to install the CPU & cooler correctly. Wrong installation will cause the damage of your CPU & mainboard.

1. Open the load lever.
2. Lift the load lever up to fully open position.




3. After confirming the CPU direction for correct mating, put down the CPU in the socket housing frame. Be sure to grasp on the edge of the CPU base. Note that the alignment keys are matched.
4. Remove the plastic cap. Engage the load lever while pressing down lightly onto the load plate.




### **Important**

Visually inspect if the CPU is seated well into the socket. If not, take out the CPU with pure vertical motion and reinstall.


5. Secure the lever near the hook end under the retention tab.




6. Make sure the four hooks are in proper position before you install the cooler. Align the holes on the mainboard with the cooler. Push down the cooler until its four clips get wedged into the holes of the mainboard.



7. Press the four hooks down to fasten the cooler. Turn over the mainboard to confirm that the clip-ends are correctly inserted.



8. Finally, attach the CPU Fan cable to the CPU fan connector on the mainboard.




### **Important**

- Confirm if your CPU cooler is firmly installed before turning on your system.
- Do not touch the CPU socket pins to avoid damaging.
- Whenever CPU is not installed, always protect your CPU socket pin with the plastic cap covered to avoid damaging.
- Please refer to the documentation in the CPU cooler package for more details about the CPU cooler installation.
- Read the CPU status in BIOS.



## Memory

These DIMM slots are used for installing memory modules. For more information on compatible components, please visit <http://www.msi.com/service/test-report>



### Dual-Channel mode Population Rule

In Dual-Channel mode, the memory modules can transmit and receive data with two data bus lines simultaneously. Enabling Dual-Channel mode can enhance the system performance. The following illustrations explain the population rules for Dual-Channel mode.




### Important

- DDR3 memory modules are not interchangeable with DDR2, and the DDR3 standard is not backwards compatible. You should always install DDR3 memory modules in the DDR3 DIMM slots.
- In Dual-Channel mode, make sure that you install memory modules of the **same type and density** in different channel DIMM slots.
- To ensure a successful system boot-up, always insert the memory modules into the DIMM1 first.
- Due to the chipset resource deployment, the system density will only be detected up to 31+GB (not full 32GB) when each DIMM is installed with a 8GB memory module.

## Installing Memory Modules

1. The memory module has only one notch on the center and will only fit in the right orientation.
2. Insert the memory module vertically into the DIMM slot. Then push it in until the golden finger on the memory module is deeply inserted in the DIMM slot. The plastic clip at each side of the DIMM slot will automatically close when the memory module is properly seated.
3. Manually check if the memory module has been locked in place by the DIMM slot clips at the sides.



### **Important**

*You can barely see the golden finger if the memory module is properly inserted in the DIMM slot.*




## Power Supply

### ATX 24-pin Power Connector: JPWR1


This connector allows you to connect an ATX 24-pin power supply. To connect the ATX 24-pin power supply, make sure the plug of the power supply is inserted in the proper orientation and the pins are aligned. Then push down the power supply firmly into the connector.

You may use the 20-pin ATX power supply as you like. If you'd like to use the 20-pin ATX power supply, please plug your power supply along with pin 1 & pin 13.



### ATX 8-pin Power Connector: JPWR2


This connector is used to provide the power output to the CPU.



### **Important**

*Make sure that all the connectors are connected to proper ATX power supplies to ensure stable operation of the mainboard.*

## Back Panel



### ► Mouse/Keyboard

The standard PS/2® mouse/keyboard DIN connector is for a PS/2® mouse/keyboard.

### ► USB 2.0 Port

The USB (Universal Serial Bus) port is for attaching USB devices such as keyboard, mouse, or other USB-compatible devices.

### ► USB 3.0 Port

USB 3.0 port is backward-compatible with USB 2.0 devices. Supports data transfer rate up to 5 Gbit/s (SuperSpeed).

## **Important**

*If you want to use a USB 3.0 device, you must use the USB 3.0 cable to connect to the USB 3.0 port.*

### ► Clear CMOS Button

There is a CMOS RAM on board that has a power supply from external battery to keep the system configuration data. With the CMOS RAM, the system can automatically boot OS every time it is turned on. If you want to clear the system configuration, use the button to clear data. Press the button to clear the data.

## **Important**

- *Make sure that you power off the system before clearing CMOS data.*
- *After pressing this button to clear CMOS data in power off (G3) state, the system will boot automatically.*

### ► Coaxial S/PDIF-Out

This SPDIF (Sony & Philips Digital Interconnect Format) connector is provided for digital audio transmission to external speakers through a coaxial cable.

### ► Optical S/PDIF-Out

This S/PDIF (Sony & Philips Digital Interconnect Format) connector is provided for digital audio transmission to external speakers through an optical fiber cable.

### ► HDMI Port

The High-Definition Multimedia Interface (HDMI) is an all-digital audio/video interface capable of transmitting uncompressed streams. HDMI supports all TV format, including standard, enhanced, or high-definition video, plus multi-channel digital audio on a single cable.

### ► VGA Port

The DB15-pin female connector is provided for monitor.


### ► DVI-D Port

The DVI-D (Digital Visual Interface-Digital) connector allows you to connect a LCD monitor. It provides a high-speed digital interconnection between the computer and its display device. To connect an LCD monitor, simply plug your monitor cable into the DVI-D connector, and make sure that the other end of the cable is properly connected to your monitor (refer to your monitor manual for more information).

## **Important**

*The HDMI, VGA and DVI-D ports on the mainboard are designed to serve as IGP (Integrated Graphics Processor) used. If you installed a processor without integrated graphics chip, these display ports will have no effect.*

### ► LAN

The standard RJ-45 LAN jack is for connection to Yellow —  — Green/ Orange the Local Area Network (LAN). You can connect a network cable to it.

LED	Color	LED State	Condition
Left	Yellow	Off	LAN link is not established.
		On(Steady state)	LAN link is established.
		On(brighter & pulsing)	The computer is communicating with another computer on the LAN.
Right	Green	Off	10 Mbits/sec data rate is selected.
		On	100 Mbits/sec data rate is selected.
	Orange	On	1000 Mbits/sec data rate is selected.

### ► Audio Ports


These audio connectors are used for audio devices. It is easy to differentiate between audio effects according to the color of audio jacks.

- Line-In: Blue - Line In, is used for external CD player, tape-player or other audio devices.
- Line-Out: Green - Line Out, is a connector for speakers or headphones.
- Mic: Pink - Mic, is a connector for microphones.
- RS-Out: Black - Rear-Surround Out in 4/ 5.1/ 7.1 channel mode.
- CS-Out: Orange - Center/ Subwoofer Out in 5.1/ 7.1 channel mode.
- SS-Out: Gray - Side-Surround Out in 7.1 channel mode.


# Connectors

## Serial ATA Connector: SATA1~8

This connector is a high-speed Serial ATA interface port. Each connector can connect to one Serial ATA device.



\* The MB layout in this figure is for reference only.



SATA1~2 (6Gb/s)  
supported by Intel® Z68

SATA3~6 (3Gb/s)  
supported by Intel® Z68


SATA7~8 (6Gb/s)  
supported by Marvell® 9128 (optional)

### **Important**

Please do not fold the Serial ATA cable into 90-degree angle. Otherwise, data loss may occur during transmission.


## Serial Port Connector: JCOM1

This connector is a 16550A high speed communication port that sends/receives 16 bytes FIFOs. You can attach a serial device.



## Fan Power Connectors: CPUFAN, SYSFAN1~4

The fan power connectors support system cooling fan with +12V. When connecting the wire to the connectors, always note that the red wire is the positive and should be connected to the +12V; the black wire is Ground and should be connected to GND. If the mainboard has a System Hardware Monitor chipset on-board, you must use a specially designed fan with speed sensor to take advantage of the CPU fan control.



### **Important**


- Please refer to the recommended CPU fans at processor's official website or consult the vendors for proper CPU cooling fan.
- CPUFAN, SYSFAN1 support Smart fan control. You can install **Control Center** utility that will automatically control the fan speeds according to the actual temperatures.
- Fan cooler set with 3 or 4 pins power connector are both available for CPUFAN and SYSFAN1.

## Front USB Connector: JUSB1 / JUSB2 / JUSB3

This connector, compliant with Intel® I/O Connectivity Design Guide, is ideal for connecting high-speed USB interface peripherals such as USB HDD, digital cameras, MP3 players, printers, modems and the like.

The **JUSB1 (red mark)** supports the MSI newly Super-Charger technology which provides fast charging function anytime for charging your Smartphone.

If your system is in S0 / S1 state, you must install MSI's application, SuperCharger, to control the **JUSB1**. When the application is set to "On", it can fast charge Smartphone via **JUSB1** but the data transmission and synchronization will be disabled. When the application is set to "Off", the **JUSB1** will work as a normal USB connector. In S3 / S4 / S5 state, **JUSB1** can still provides fast charging function without operating system, no matter you un-plug and re-plug the Smartphone.




### **Important**

- Note that the pins of VCC and GND must be connected correctly to avoid possible damage.
- For iPad, **JUSB1 (red mark)** can still charge iPad in S3, S4, S5 state.
- Please note that connecting one device once for stable charging is recommended.
- Super-Charger technology would be available on specific models, please refer to MSI website for model support list.
- We recommend that don't disconnect the device when you charge it in S1 state.

## Front USB Connector: JUSB4

USB 3.0 port is backward-compatible with USB 2.0 devices. Supports data transfer rate up to 5 Gbit/s (SuperSpeed).




### **Important**

- Note that the pins of VCC and GND must be connected correctly to avoid possible damage.
- If you want to use a USB 3.0 device, you must use the USB 3.0 cable to connect to the USB 3.0 port.


## Front Panel Audio Connector: JAUD1

This connector allows you to connect the front panel audio and is compliant with Intel® Front Panel I/O Connectivity Design Guide.



**TPM Module connector: JTPM1**


This connector connects to a TPM (Trusted Platform Module) module (optional). Please refer to the TPM security platform manual for more details and usages.



\* The MB layout in this figure is for reference only.

**S/PDIF-Out Connector: JSP1**

This connector is used to connect S/PDIF (Sony & Philips Digital Interconnect Format) interface for digital audio transmission.




\* The MB layout in this figure is for reference only.




## Chassis Intrusion Connector: JCI1

This connector connects to the chassis intrusion switch cable. If the chassis is opened, the chassis intrusion mechanism will be activated. The system will record this status and show a warning message on the screen. To clear the warning, you must enter the BIOS utility and clear the record.




## Front Panel Connectors: JFP1, JFP2

These connectors are for electrical connection to the front panel switches and LEDs. The JFP1 is compliant with Intel® Front Panel I/O Connectivity Design Guide.



## DLED3 Connector: JDLED3 (optional)

This is reserved for connecting the MSI future control card.



## Buttons

---

The mainboard provides the following buttons for you to set the computer's function. This section will explain how to change your mainboard's function through the use of button.

### OC Genie Button: TURBO1

This button is used to auto-overclock for the system. Press this button to enable the OC Genie function when the system is in power off state, meanwhile, the button will light and lock. And then the system will automatically detect the optimum values to overclock after booting the system. To disable the OC Genie function, please press the button again after power off the system, meanwhile, the button light will off and unlock, and the system will restore the default for next boot.



### Important

- Please install the DDR3 1333 and up memory and equip better heat sink/ cooler with OC Genie function.
- We do not guarantee the OC Genie overclocking range and the damages or risks caused by the OC Genie overclocking behavior.
- You can disable the OC Genie function in BIOS setup. And we suggest you to save the OC Genie configuration to overclocking profile in BIOS for future using.

---

### Power Button: POWER1

This button is used to turn-on or turn-off the system. Press the button to turn-on or turn-off the system.



---

### Reset Button: RESET1



This button is used to reset the system. Press the button to reset the system.




## Voltage Check Point

### Voltage Check Point: FV1


This voltage check point set is used to measure the current CPU/ CPU\_VTT/ CPU\_GFX/ DDR/ PCH voltage.




CPU voltage: measure the current CPU voltage with CPU point and GND point by using a multimeter.




CPU\_VTT voltage: measure the current CPU\_VTT voltage with CPU\_VTT point and GND point by using a multimeter.



CPU\_GFX voltage: measure the current CPU Integrated Graphic voltage with CPU\_GFX point and GND point by using a multimeter.




DDR voltage: measure the current DDR voltage with DDR point and GND point by using a multimeter.



PCH voltage: measure the current PCH voltage with PCH point and GND point by using a multimeter.

## LED Status Indicators



### CPU Phase LEDs

These LEDs indicate the current CPU power phase mode. Follow the instructions below to read.

■ Lights      □ Off

■ □ □ □ □ □	CPU is in 1 phase power mode.
■ ■ □ □ □ □	CPU is in 2 phase power mode.
■ ■ ■ □ □ □	CPU is in 3 phase power mode.
■ ■ ■ ■ □ □	CPU is in 4 phase power mode.
■ ■ ■ ■ ■ □	CPU is in 5 phase power mode.
■ ■ ■ ■ ■ ■	CPU is in 6 phase power mode.

### Dual BIOS LED

The Dual BIOS LED indicates the BIOS status during system power on. Follow the instructions below to read.

Off: Normal.

Blink (1 cycle/second): The primary BIOS failed.

Solid: Both primary and secondary BIOS failed.

## Jumper

### Clear CMOS Jumper: JBAT1

There is a CMOS RAM onboard that has a power supply from an external battery to keep the data of system configuration. With the CMOS RAM, the system can automatically boot OS every time it is turned on. If you want to clear the system configuration, set the jumper to clear data.

JBAT1



Keep Data



Clear Data


### **Important**

*You can clear CMOS by shorting 1-2 pin while the system is off, then open it. Avoid clearing the CMOS while the system is on; it will damage the mainboard.*

## Slots

### PCIE (Peripheral Component Interconnect Express) Slot

The PCIE slot supports the PCIE interface expansion card.




#### **Important**

*When adding or removing expansion cards, make sure that you unplug the power supply first. Meanwhile, read the documentation for the expansion card to configure any necessary hardware or software settings for the expansion card, such as jumpers, switches or BIOS configuration.*

### PCI (Peripheral Component Interconnect) Slot

The PCI slot supports LAN card, SCSI card, USB card, and other add-on cards that comply with PCI specifications.




#### **Important**

*When adding or removing expansion cards, make sure that you unplug the power supply first. Meanwhile, read the documentation for the expansion card to configure any necessary hardware or software settings for the expansion card, such as jumpers, switches or BIOS configuration.*

### PCI Interrupt Request Routing

The IRQ, acronym of interrupt request line and pronounced I-R-Q, are hardware lines over which devices can send interrupt signals to the microprocessor. The PCI IRQ pins are typically connected to the PCI bus pins as follows:

	Order1	Order2	Order3	Order4
PCI Slot1	INT A#	INT B#	INT C#	INT D#
PCI Slot2	INT B#	INT C#	INT D#	INT A#



## Chapter 3

# BIOS Setup

This chapter provides information on the BIOS Setup program and allows you to configure the system for optimum use.

You may need to run the Setup program when:

- An error message appears on the screen during the system booting up, and requests you to run SETUP.
- You want to change the default settings for customized features.

## Entering Setup

---

Power on the computer and the system will start POST (Power On Self Test) process. When the message below appears on the screen, press <DEL> key to enter Setup.

### Press DEL to enter Setup Menu, F11 to enter Boot Menu

If the message disappears before you respond and you still wish to enter Setup, restart the system by turning it OFF and On or pressing the RESET button. You may also restart the system by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys.

### **Important**

- The items under each BIOS category described in this chapter are under continuous update for better system performance. Therefore, the description may be slightly different from the latest BIOS and should be held for reference only.
- Upon boot-up, the 1st line appearing after the memory count is the BIOS version. It is usually in the format:

*E7681IMS.xxx 051211 where:*

*1st digit refers to BIOS type as E = EFI*

*2nd - 5th digit refers to the model number.*

*6th digit refers to the chipset as I = Intel, N = nVidia, A = AMD and V = VIA.*





*7th - 8th digit refers to the customer as MS = all standard customers.*

*xxx refers to the BIOS version.*

*051211 refers to the date this BIOS was released.*




## Control

Keyboard	Mouse	Description
<↑ ↓ >	 Move the cursor	Select Item
<Enter>	 Click/ Double-click the left button	Select Icon/ Field
<Esc>	 Click the right button	Jumps to the Exit menu or returns to the previous from a submenu
<+>		Increase the numeric value or make changes
<->		Decrease the numeric value or make changes
<F1>		General Help
<F4>		CPU Specifications
<F5>		Enter Memory-Z
<F6>		Load optimized defaults
<F10>		Save Change and Reset
<Esc>		Exit

## Sub-Menu

If you find a right pointer symbol (as shown in the right view) appears to the left of certain fields that means a sub-menu can be launched from this field. A sub-menu contains additional options for a field parameter. You can use arrow keys ( ↑ ↓ ) or mouse to highlight the field and press <Enter> or double-click the left mouse button to enter the sub-menu. Then you can use the control keys to enter values and move from field to field within a sub-menu. If you want to return to the previous menu, just press the <Esc > or click the right mouse button.



## General Help <F1>

The BIOS setup program provides a General Help screen. You can call up this screen from any menu by simply pressing <F1>. The Help screen lists the appropriate keys to use and the possible selections for the highlighted item. Press <Esc> to exit the Help screen.

## The Main Menu



### ► Language

After entering the Setup menu, you can see a “Language” button. Please click it and select the language, at your desire, for the BIOS setting first.

### ► Green Power

Click “Green Power” icon to enter the menu. Use this menu to specify the power phase.

### ► Utilities

Click “Utilities” icon to enter the menu. This menu provides the useful utility for you to live update bios and hard disk backup.

### ► Overclocking

Click “Overclocking” icon to enter the menu. Use this menu to specify your settings for frequency/voltage control and overclocking.


### ► Games

Click “Games” icon to enter the menu. This menu provides several games for you to play.

### ► Settings

Click “Settings” icon to enter the menu. Use this menu to specify your settings for chip-set features, boot device and password.

## Green Power



### ► EuP 2013

This item is designed for Energy Using Products Lot 6 2013 (EuP) aka Energy Related Products (ErP). To reduce Power Consumption when system off or standby mode.

Note: When “Enabled” EuP 2013 setting, system don’t support RTC wake up event function.

### ► CPU Phase Control

These items allow you to select the power phase mode to reach the best power saving function.

### ► Motherboard LED Control

This item allows you to enable (Auto)/ disable (disabled) the motherboard phase LED.

### ► C1E

Enable this item to reduce the CPU power consumption while idle. Not all processors support Enhanced Halt state (C1E).

### ► Intel C-State

C-state is a power management state that significantly reduces the power of the processor during idle. This field will appear after you installed the CPU which support c-state technology.

### ► Package C State limit

This feild allows you to select a C-state mode.

## Utilities



### ► Memory Test

This item is used to test installed memory.

### ► Live Update

Live Update is a tool used to detect and update your BIOS online so that you don't need to search for the correct BIOS version throughout the website.

### ► HDD Backup

This item is used to backup hard disk. Hard disk store backup and restore is one of the most common and important task. It consists of backing up all the partition on image files. When the data is lost or problems occur, you can restore the partition image to keep your system.


### ► Boot Screen

This item is used to select the boot screen.

## **Important**

- Before you enter to the Live Update/ HDD Backup menu, please place the MSI Driver DVD that be included in the mainboard package into the DVD-ROM drive . The Driver DVD provides the necessary programs for these two utility.
- The Boot Screen utility can only support the jpg/ bmp format image file in 1024 x 768 dpi that saved in FAT12/ 16/ 32 formats storage device.

## Overclocking



### ► Current CPU / DRAM Frequency

These items show the current clocks of CPU and Memory speed. Read-only.

### ► CPU Base Frequency [10KHz]

This item allows you to set the CPU Base clock (in 10KHz). You may overclock the CPU by adjusting this value. Please note the overclocking behavior is not guaranteed.

### ► Adjust CPU Ratio

This item controls the multiplier that is used to determine the internal clock speed of the processor relative to the external or motherboard clock speed. It is available only when the processor supports this function.

### ► Adjusted CPU Frequency

It shows the adjusted CPU frequency. Read-only.

### ► Adjust CPU Ratio in OS

Enable this item, it will allow you to change the CPU ratio in OS by using MSI application.

### ► Internal PLL Overvoltage

This item are used to adjust the PLL voltage.

►EIST

The Enhanced Intel SpeedStep technology allows you to set the performance level of the microprocessor whether the computer is running on battery or AC power. This field will appear after you installed the CPU which supports speedstep technology.

► DRAM Frequency

This setting controls the frequency of memory.

► Extreme Memory Profile(X.M.P)

This item is used to enable/disable the Intel Extreme Memory Profile (XMP). For further information please refer to Intel's official website.

► Adjusted DRAM Frequency


It shows the adjusted DRAM frequency. Read-only.

► DRAM Timing Mode

Select whether DRAM timing is controlled by the SPD (Serial Presence Detect) EEPROM on the DRAM module. Setting to [Auto] enables DRAM timings and the following "Advanced DRAM Configuration" sub-menu to be determined by BIOS based on the configurations on the SPD. Selecting [Link] or [Unlink] allows users to configure the DRAM timings and the following related "Advanced DRAM Configuration" sub-menu manually.

► Advanced DRAM Configuration

Press <Enter> to enter the sub-menu.



► Command Rate2

This setting controls the DRAM command rate.

► tCL

This controls the CAS latency, which determines the timing delay (in clock cycles) before SDRAM starts a read command after receiving it.

► tRCD

When DRAM is refreshed, both rows and columns are addressed separately. This setup item allows you to determine the timing of the transition from RAS (row address strobe) to CAS (column address strobe). The less the clock cycles, the faster the DRAM performance.

#### ► tRP

This setting controls the number of cycles for Row Address Strobe (RAS) to be allowed to precharge. If insufficient time is allowed for the RAS to accumulate its charge before DRAM refresh, refreshing may be incomplete and DRAM may fail to retain data. This item applies only when synchronous DRAM is installed in the system.

#### ► tRAS

This setting determines the time RAS takes to read from and write to memory cell.

#### ► tRFC

This setting determines the time RFC takes to read from and write to a memory cell.

#### ► tWR

Minimum time interval between end of write data burst and the start of a precharge command. Allows sense amplifiers to restore data to cells.

#### ► tWTR

Minimum time interval between the end of write data burst and the start of a column-read command. It allows I/O gating to overdrive sense amplifiers before read command starts.

#### ► tRRD

Specifies the active-to-active delay of different banks.

#### ► tRTP

Time interval between a read and a precharge command.

#### ► tFAW

This item is used to set the tFAW (four activate window delay) timing.

#### ► tWCL

This item is used to set the tWCL (Write CAS Latency) timing.

#### ► tCKE

This item is used to set the tCKE timing.

#### ► Advanced Channel 1/ 2 Timing Configuration

Press <Enter> to enter the sub-menu. And you can set the advanced memory timing for each channel.



#### ► tRRDR/ tRRDD/ tWWDR/ tWWDD/ tRWDRDD/ tWRD (1/ 2)

These items are used to set the memory timings for memory channel 1/ 2.

#### ► GT OverClocking

This item allows you to enable/ disable the overclocking of integrated graphics.

#### ► GT Ratio

This setting controls the ratio of integrated graphics frequency to enable the integrated graphics to run at different frequency combinations.

## ► Spread Spectrum

When the mainboard's clock generator pulses, the extreme values (spikes) of the pulses create EMI (Electromagnetic Interference). The Spread Spectrum function reduces the EMI generated by modulating the pulses so that the spikes of the pulses are reduced to flatter curves.

## ***Important***

- *If you do not have any EMI problem, leave the setting at [Disabled] for optimal system stability and performance. But if you are plagued by EMI, select the value of Spread Spectrum for EMI reduction.*
- *The greater the Spread Spectrum value is, the greater the EMI is reduced, and the system will become less stable. For the most suitable Spread Spectrum value, please consult your local EMI regulation.*
- *Remember to disable Spread Spectrum if you are overclocking because even a slight jitter can introduce a temporary boost in clock speed which may just cause your over-clocked processor to lock up.*

## ► VDroop Control

This item is used to select the VDroop control mode.

## ► CPU Core Voltage/ CPU I/O Voltage/ DRAM Voltage/ GPU Voltage/ System Agent Voltage(SA)/ CPU PLL Voltage/ DDR\_VREF\_CA\_A/ DDR\_VREF\_CA\_B/ DDR\_VREF\_DA\_A/ DDR\_VREF\_DA\_B/ PCH 1.05


These items are used to adjust the voltage of CPU, Memory and chipset.

## ► Current CPU Core Voltage/ Current CPU I/O Voltage/ Current DRAM Voltage/ Current GPU Voltage

These items show current CPU Core/ CPU I/O/ DRAM/ GPU voltage. Read-only.

## ► Overclocking Profiles

Press <Enter> to enter the sub-menu.



## ► Overclocking Profile 1/ 2/ 3/ 4/ 5/ 6

Press <Enter> to enter the sub-menu. In the sub-menu, these items are used to save the current settings, and you can to load the settings from the stored profile.


## ► OC Retry Count

When overclocking has failed, setting this item as [1, 3] will allow system to reboot 1/ 3 times with the same overclocked configuration. If overclocking has failed every time, the system will restore the defaults.



### ► CPU Specifications

Press <Enter> to enter the sub-menu. The sub-menu shows the information of installed CPU.



### ► CPU Technology Support

Press <Enter> to enter the sub-menu. The sub-menu shows the installed CPU technologies. Read only.

### ► MEMORY-Z

Press <Enter> to enter the sub-menu.



### ► DIMM1~4 Memory SPD


Press <Enter> to enter the sub-menu. The sub-menu displays the informations of installed memory.

### ► X.M.P Support Information

Press <Enter> to enter the sub-menu. These items display the current status of the X.M.P support information. Read only.

### ► CPU Features

Press <Enter> to enter the sub-menu and the following screen appears:



### ► Hyper-threading

The processor uses Hyper-Threading technology to increase transaction rates and reduces end-user response times. The technology treats the two cores inside the processor as two logical processors that can execute instructions simultaneously. In this way, the system performance is highly improved. If you disable the function, the processor will use only one core to execute the instructions. Please disable this item if your operating system doesn't support HT Function, or unreliability and instability may occur.

## **Important**

Enabling the functionality of Hyper-Threading Technology for your computer system requires ALL of the following platform Components:

- *CPU: An Intel® Processor with HT Technology;*
- *Chipset: An Intel® Chipset that supports HT Technology;*
- *BIOS: A BIOS that supports HT Technology and has it enabled;*
- *OS: An operating system that supports HT Technology.*

*For more information on Hyper-threading Technology, go to:*

*<http://www.intel.com/technology/platform-technology/hyper-threading/>*

► **Active Processor Cores**

This item allows you to select the number of active processor cores.

► **Limit CPUID Maximum**

It is designed to limit the listed speed of the processor to older operating systems.

► **Execute Disable Bit**

Intel's Execute Disable Bit functionality can prevent certain classes of malicious "buffer overflow" attacks when combined with a supporting operating system. This functionality allows the processor to classify areas in memory by where application code can execute and where it cannot. When a malicious worm attempts to insert code in the buffer, the processor disables code execution, preventing damage or worm propagation.

► **Intel Virtualization Tech**

This item is used to enable/disable the Intel Virtualization technology. For further information please refer to Intel's official website.

► **Intel VT-D Tech**

This item is used to enable/disable the Intel VT-D technology. For further information please refer to Intel's official website.

► **Power Technology**

This item allows you to select the Intel Dynamic Power technology mode.

► **C1E Support**

To enable this item to read the CPU power consumption while idle. Not all processors support Enhanced Halt state (C1E).

► **OverSpeed Protection**

Overspeed Protection function can monitor the current CPU draws as well as its power consumption. If it exceeds a certain level, the processor automatically reduces its clock speed. If you want to overclock your CPU, set it to [Disabled].

► **Intel C-State**

C-state is a power management state that significantly reduces the power of the processor during idle. This field will appear after you installed the CPU which supports c-state technology.

► **Package C-State limit**

This field allows you to select a C-state mode.

► **Long duration power limit(W)**

This field allows you to adjust the TDP limit for the long duration.

► **Long duration maintained(ms)**

This field allows you to adjust the maintaining time for long duration power limit.


► **Short duration power limit(W)**

This field allows you to adjust the TDP limit for the short duration.

► **Primary plane turbo power limit(W)**

This field allows you to adjust the TDP limit for the primary plane turbo.

## Games



This menu provides several games for you to play. Simply click any icon to enter it and following the game rules to play it.


### **Important**

*Before you enter to the Game menu, please place the MSI Driver DVD that be included in the mainboard package into the DVD-ROM drive . This DVD provides the necessary programs for the game utility.*

## Settings



## System Status



### ► System Date

This allows you to set the system to the date that you want (usually the current date). The format is <day> <month> <date> <year>.

- day Day of the week, from Sun to Sat, determined by BIOS. Read-only.
- month The month from Jan. through Dec.
- date The date from 1 to 31 can be keyed by numeric function keys.
- year The year can be adjusted by users.

► System Time

This allows you to set the system time that you want (usually the current time). The time format is <hour> <minute> <second>.

► SATA Port1~6

It will show the device information that you connected to the SATA connector.


**Important**

*SATA Port1~6 are available when you connect the HDD devices to the SATA connectors on the mainboard.*

► System Information


It shows the information of your system (read only).

Advance



► PCI Subsystem Settings

Press <Enter> to enter the sub-menu.



► PCI Latency Timer

This item controls how long each PCI device can hold the bus before another takes over. When set to higher values, every PCI device can conduct transactions for a longer time and thus improve the effective PCI bandwidth. For better PCI performance, you should set the item to higher values.

► ACPI Settings

Press <Enter> to enter the sub-menu.



► ACPI Standby State

This item specifies the power saving modes for ACPI function.

► Power LED

This item configures how the system uses power LED on the case to indicate the sleep/suspend state.

### ► Integrated Peripherals

Press <Enter> to enter the sub-menu.



#### == Onboard Lan Configuration ==

##### ► Onboard Lan Controller1

This item allows you to enable/ disable the onboard LAN1/ 2 controller.

##### ► LAN Option ROM

This item is used to decide whether to invoke the Boot ROM of the onboard LAN.

#### == SATA Configuration ==

##### ► SATA Mode

This item is used to specify RAID/ IDE/ AHCI mode for SATA1~6 port.

#### == External SATA 6GB/s Configuration ==

##### ► External SATA 6GB/s Controller Mode (for Z68A-GD65 only)

This item is used to specify RAID/ IDE/ AHCI mode for SATA7~8 port.

#### == Audio Configuration ==

##### ► HD Audio Controller

This item allows you to enable/ disable the HD audio controller.


#### == HPET Configuration ==

##### ► HPET

The HPET (High Precision Event Timers) is a component that is part of the chipset. You can to enable it, and will provide you with the means to get to it via the various ACPI methods.

### ► USB Configuration

Press <Enter> to enter the sub-menu.



##### ► USB Devices:

This item shows the type of installed USB device.

##### ► USB Controller

This item allows you to enable/ disable the USB controller.

##### ► Legacy USB Support

This item allows you to enable/ disable the legacy USB support for USB keyboards, mice and floppy drives. You will be able to use these USB devices with operating systems that do not support USB.

► Onboard USB 3.0 Controller

This item allows you to enable/ disable the USB 3.0 controller.

► USB3.0 Legacy Mode Support

Select [Enabled] if you need to use a USB3.0-interfaced device in the operating system.

► Super IO Configuration

Press <Enter> to enter the sub-menu.



► Serial(COM) Port 0 Configuration

Press <Enter> to enter the sub-menu.



► Serial(COM) Port0


This item allows you to enable/ disable the serial port.

► Serial(COM) Port0 Settings

Select an address and corresponding interrupt for the serial port.

► H/W Monitor

Press <Enter> to enter the sub-menu.



► CPU Smart Fan Target

The Smart Fan function controls the CPU fan speed automatically depending on the current temperature to keep it with in a specific range. You can enable a fan target value here. If the current CPU fan temperature reaches to the target value, the smart fan function will be activated.

► SYS Fan 1/ 2 Control

These items allow users to select how percentage of speed for the SYSFAN1/ 2.

► CPU/ System Temperature, CPU FAN/ SYS FAN 1/ 2 Speed

These items show the current status of all of the monitored hardware devices/components such as CPU voltage, temperatures and all fans' speeds.

► Power Management Setup

Press <Enter> to enter the sub-menu.



► EUP 2013

This item is designed for Energy Using Products Lot 6 2013 (EuP) aka Energy Related Products (ErP). To reduce Power Consumption when system off or standby mode.

Note: When "Enabled" EuP 2013 setting, system don't support RTC wake up event function.




### ► Restore on AC Power Loss

This item specifies whether your system will reboot after a power failure or interrupt occurs. Settings are:

- [Power Off] Always leaves the computer in the power off state.
- [Power On] Always leaves the computer in the power on state.
- [Last State] Restore the system to the status before power failure or interrupt occurred.

### ► Wake Up Event Setup

Press <Enter> to enter the sub-menu.



### ► Wake Up Event By

Setting to [BIOS] activates the following fields, and use the following fields to set the wake up events. Setting to [OS], the wake up events will be defined by OS.

### ► Resume By RTC Alarm

The field is used to enable or disable the feature of booting up the system on a scheduled time/date.

### ► Date/ HH:MM:SS

If Resume By RTC Alarm is set to [Enabled], the system will automatically resume (boot up) on a specific date/hour/minute/second specified in these fields (using the <+> and <-> to select the date & time settings).

### ► Resume By PCI or PCI-E Device

When set to [Enabled], the feature allows your system to be awakened from the power saving modes through any event on PCI or PCIE device.


### ► Resume From S3 by USB Device

The item allows the activity of the USB device to wake up the system from S3 (Suspend to RAM) sleep state.

### ► Resume From S3/S4/S5 by PS/2 Mouse/ Keyboard

These items determine whether the system will be awakened from what power saving modes when input signal of the PS/2 mouse/ keyboard is detected.

## M-Flash



### ► BIOS Boot Function

This allows you to enable/ disable the system to boot from the BIOS file inside USB

drive (FAT/ 32 format only).

► **Select UEFI file to boot from**

When the BIOS Boot function as sets to [Enabled], this item is selectable. This item allows to select particular UEFI file from the USB/ Storage (FAT/ 32 format only) drive. And the system will boot from selected UEFI file.


► **Save current UEFI rom to file**

Please setup a specific folder in specific USB/ Storage drive to save UEFI file from ROM chip data. Note: it only supports FAT/ 32 file system drive.

► **Select UEFI file to flash**

This item allows you to select particular UEFI file from the USB/ Storage (FAT/ 32 format only) drive for updating BIOS.

Security



► **Administrator Password**

This item is used to set the administrator password. When a administrator password has been set, you will be prompted to enter it every time you try to enter BIOS Setup.

► **User Password**

This item is used to set the user password. When a user password has been set, you will be prompted to enter it every time you try to enter the operating system.

**Important**

*When you select the Administrator Password / User Password item, a password box will appear on the screen. Type the password, and press <Enter>. The password typed now will replace any previously set password from CMOS memory. You will be prompted to confirm the password. Retype the password and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.*

*To clear a set password, just press <Enter> when you are prompted to enter the password. A message will show up confirming the password will be disabled. Once the password is disabled, the system will boot and you can enter Setup/ OS without entering any password.*

*These two items prevent an unauthorized person from changing any part of your system configuration.*

► **U-Key**

This item is used to enable/ disable USB driver device as a key.

### ► Make U-Key at

When the “U-Key” as sets to [Enabled], this item is selectable. This item allows you to specify the USB driver device.

### ► Chassis Intrusion Configuration

Press <Enter> to enter the sub-menu.

#### ► Chassis Intrusion

This item enables or disables the feature of recording the chassis intrusion status and issuing a warning message if the chassis is once opened. To clear the warning message, set the field to [Reset]. The setting of the field will automatically return to [Enabled] later.

### ► Multi BIOS Auto Update (for Z68A-GD65 only)


When “Enabled”, and the primary BIOS has failed, the system will allow the secondary BIOS to reflash the primary BIOS for booting successfully.

The screen will show the progress message as below.

Multi BIOS auto update starting.  
Flashing... XX%

Do not press any buttons to shutdown or restart the computer during the BIOS flashing operation.

## Boot



### ► Full Screen Logo Display

This item enables this system to show the company logo on the boot-up screen. Settings are:

- [Enabled] Shows a still image (logo) on the full screen at boot.
- [Disabled] Shows the POST messages at boot.

== Set Boot Priority ==

### ► 1st/ 2nd/ 3rd/ 4th/ 5th/ 6th/ 7th/ 8th Boot

You can select the boot priorities in these items.

- ▶ **USB HardDisk Drive BBS Priorities**

- ▶ **Boot Option**


- You can select the USB hard disk drive boot priorities in these Boot Option items.

- ▶ **UEFI Boot Drive BBS Priorities**

- ▶ **Boot Option**

- You can select the UEFI boot drive priorities in these Boot Option items.

## Save & Exit



### ► Discard Changes and Exit

Use this item to abandon all changes and exit setup.

### ► Save Changes and Reset

Use this item to save changes and reset the system.

### ► Save Changes

Use this item to save changes.

### ► Discard Changes

Use this item to abandon all changes.

### ► Restore Defaults

Use this item to load the optimized default values set by the BIOS vendor.


## == Boot Override ==

The installed storage devices will appear on this menu, you can select one of them be a boot device.

### ► Built-in EFI Shell

Use this item to enter the EFI Shell.





## ***Appendix A***

# ***Realtek Audio***

The Realtek audio provides 10-channel DAC that simultaneously supports 7.1 sound playback and 2 channels of independent stereo sound output (multiple streaming) through the Front-Out-Left and Front-Out-Right channels.

## Installing the Realtek HD Audio Driver

You need to install the HD audio driver for Realtek audio codec to function properly before you can get access to 2-, 4-, 6-, 8- channel or 7.1+2 channel audio operations. Follow the procedures described below to install the drivers for different operating systems.

### Installation for Windows®

For Windows® XP, you must install Windows® XP Service Pack3 or later before installing the driver.

The following illustrations are based on Windows®7 environment and could look slightly different if you install the drivers in different operating systems.

1. Insert the application DVD into the DVD-ROM drive. The setup screen will automatically appear.
2. Click Driver tab.
3. Click AUDIO button.



4. Select Realtek HD Audio Drivers to start installing the drivers.
5. Click Next to install the Realtek High Definition Audio Driver.
6. Follow the on-screen instructions to install drivers.
7. Click Finish to restart the system.


### **Important**

*The HD Audio Configuration software utility is under continuous update to enhance audio applications. Hence, the program screens shown here in this section may be slightly different from the latest software utility and shall be held for reference only.*



## Software Configuration

After installing the audio driver, the “Realtek HD Audio Manager” icon will appear at the notification area (lower right of the screen). You may double click the icon and the GUI will pop up accordingly.



It is also available to enable the audio driver by clicking the Realtek HD Audio Manager from the Control Panel.

## Software panel overview

The following figure describes the function of the Realtek HD Audio Manager panel.

Device Selection

Application Enhancement



Volume Adjustment

Jack status panel

#### ■ Device Selection

Here you can select a audio output source to change the related options. The “check” sign (in orange) indicates the devices as default.

#### ■ Volume Adjustment

You can control the volume or balance the right/left side of the speakers that you plugged in front or rear panel by adjust the bar.

#### ■ Application Enhancement


The array of options will provide you a complete guidance of anticipated sound effect for both output and input device.

#### ■ Jack status panel

This panel depicts all render and capture devices currently connected with your computer.

### Auto popup dialog

When you plug into the device at the jack, a dialogue window will pop up asking you which device is current connected.




As you know, each jack corresponds to its default setting, you can refer to the next section “Hardware Default Setting”.


## Hardware Default Setting

The following diagrams are audio back panel default setting.


- Backpanel audio jacks to 2-channel speakers diagram




- Backpanel audio jacks to 4-channel speakers diagram




■ Backpanel audio jacks to 6-channel speakers diagram



■ Backpanel audio jacks to 8-channel speakers diagram





## ***Appendix B***

# ***Intel RAID***

This appendix will assist users in configuring and enabling RAID functionality and accelerating system on platforms

## Introduction

---

The mainboard comes with the Intel RAID controller that allows you to configure SATA hard drives as RAID sets.

SATA hard drives deliver blistering transfer speeds up to 6 Gb/s. Serial ATA uses long, thin cables, making it easier to connect your drive and improving the airflow inside your PC. The most outstanding features are:

1. Supports 3 Gb/s or 6 Gb/s transfers with CRC error checking.
2. Supports Hot-plug-n-play feature.
3. Data handling optimizations including tagged command queuing, elevator seek and packet chain command.

Intel® RAID controller offers RAID level 0 (Striping), RAID level 1 (Mirroring and Duplexing), RAID level 5 (Block Interleaved Distributed Parity), RAID level 10 (A Stripe of Mirrors) , Intel® Rapid Storage Technology.

RAID 0 breaks the data into blocks which are written to separate hard drives. Spreading the hard drive I/O load across independent channels greatly improves I/O performance.

RAID 1 provides data redundancy by mirroring data between the hard drives and provides enhanced read performance.

RAID 5 Provides data striping at the byte level and also stripe error correction information. This results in excellent performance and good fault tolerance. Level 5 is one of the most popular implementations of RAID.

RAID 10 Not one of the original RAID levels, multiple RAID 1 mirrors are created, and a RAID 0 stripe is created over these.

Intel® Rapid Storage Technology is the advanced ability for two RAID volumes to share the combined space of two hard drives being used in unison.

Intel® Rapid Storage Technology utilizes RAID 1 functionality to copy data from a designated Master drive to a designated Recovery drive. The size of the Master drive must be less than or equal to the size of the Recovery drive. When a Recovery volume is created, complete capacity of the Master drive will be used as the Master volume. Only one Recovery Volume can exist on a system. There are 2 methods of updating the data on the Master to the Recovery drive. They are Continuous Update Policy and On Request Update Policy.

### **Important**

*The least number of hard drives for RAID 0, RAID 1, Recovery or Matrix mode is 2. The least number of hard drives for RAID 10 mode is 4. And the least number of hard drives for RAID 5 mode is 3.*

*All the information/ volumes/ pictures listed in your system might differ from the illustrations in this appendix.*

## Using Intel Rapid Storage Technology Option ROM

The Intel Rapid Storage Technology Option ROM should be integrated with the system BIOS on all mainboards with a supported Intel chipset. The Intel Rapid Storage Technology Option ROM is the Intel RAID implementation and provides BIOS and DOS disk services. Please use <Ctrl> + <I> keys to enter the "Intel® RAID for Serial ATA" status screen, which should appear early in system boot-up, during the POST (Power-On Self Test). Also, you need to enable the RAID function in BIOS to create, delete and reset RAID volumes.

### Creating, Deleting and Resetting RAID Volumes:

The Serial ATA RAID volume may be configured using the RAID Configuration utility stored within the Intel RAID Option ROM. During the Power-On Self Test (POST), the following message will appear for a few seconds.

### **Important**

*The "Device Model", "Serial #" and "Size" in the following example might be different from your system.*

```

RAID Volumes
None defined.

Physical Disks:
Port  Device Model      Serial #      Size      Type/Status(Vol ID)
1      XXXXXXXXXXXXX    XXXXXXXXXXXXX  XXX.XGB   Non-RAID Disk
2      XXXXXXXXXXXXX    XXXXXXXXXXXXX  XXX.XGB   Non-RAID Disk

Press <CTRL-I> to enter Configuration Utility..


```

After the above message shows, press <Ctrl> and <I> keys simultaneously to enter the Intel Rapid Storage Technology Option ROM.

### **Important**


*The following procedure is only available with a newly-built system or if you are reinstalling your OS. It should not be used to migrate an existing system to RAID.*

After pressing the <Ctrl> and <I> keys simultaneously, the following window will appear:



■ Create RAID Volume

- 1. Select option 1 “Create RAID Volume” and press <Enter> key. The following screen appears. Then in the Name field, specify a RAID Volume name and then press the <TAB> or <Enter> key to go to the next field.
- 2. Use the arrow keys to select the RAID level best suited to your usage model in RAID Level.





3. In the Disk field, press <Enter> key and use <Space> key to select the disks you want to create for the RAID volume, then click <Enter> key to finish selection. This field will become available according to the selected RAID level.
4. Then select the strip size for the RAID array by using the "upper arrow" or "down arrow" keys to scroll through the available values, and pressing the <Enter> key to select and advance to the next field. The available values range from 4KB to 128 KB in power of 2 increments. The strip size should be chosen based on the planned drive usage. Here are some typical values: RAID0 -128KB / RAID10 - 64KB / RAID5 - 64KB. This field will become available according to the selected RAID level.
5. Then select the capacity of the volume in the Capacity field. The default value is the maximum volume capacity of the selected disks.

The screenshot shows a terminal window with the following content:

```

[ CREATE VOLUME MENU ]
Name : Volume0
RAID Level : RAID1(Mirror)
Disks : Select Disks
Strip Size : N / A
Capacity : XXXX GB
Sync : N / A
Create Volume
  
```

Below this menu is a [ HELP ] section with the following text:

```

[ HELP ]

The default value indicates the maximum capacity using the selected
disks. Entering a lower capacity allows you to create a second
volume on these disks.
  
```

At the bottom of the terminal window, there is a navigation bar with the following options:


```

[ + ] - Change   [TAB] - Next   [ESC] - Previous Menu   [ENTER] - Select
  
```


### **Important**

Since you want to create two volumes, this default size (maximum) needs to be reduced. Type in a new size for the first volume. As an example: if you want the first volume to span the first half of the two disks, re-type the size to be half of what is shown by default. The second volume, when created, will automatically span the remainder of two hard drives.

6. Go to the Create Volume field and press <Enter>, the following screen appears for you to confirm if you are sure to create the RAID volume. Press <Y> to continue.



7. Then the following screen appears to indicate that the creation is finished.




## ■ Delete RAID Volume

Here you can delete the RAID volume, but please be noted that all data on RAID drives will be lost.

### ***Important***

*If your system currently boots to RAID and you delete the RAID volume in the Intel RAID Option ROM, your system will become un-bootable.*


Select option 2 **Delete RAID Volume** from the main menu screen and press <Enter> key to select a RAID volume for deletion. Then press <Delete> key to delete the selected RAID volume. The following screen appears.



Press <Y> key to accept the volume deletion.

■ **Reset Disks to Non-RAID**

Select option 3 Reset Disks to Non-RAID and press <Enter> to delete the RAID volume and remove any RAID structures from the drives. The following screen appears:




Use the <Space> key to select the disks and press <Enter> key. A confirmation sentence will appear below, and then press <Y> key to accept the selection.

**Important**

- You will lose all data on the RAID drives and any internal RAID structures when you perform this operation.
- Possible reasons to “Reset Disks to Non-RAID” could include issues such as incompatible RAID configurations or a failed volume or failed disk.

### ■ Recovery Volume Options

Select option 4 Recovery Volume Options and press <Enter> to change recovery volume mode. The following screen appears:



Recovery mode will change from Continuous Update to On-Request after you enable "Only Recovery Disk" or "Only Master Disk".

## Installing Driver

---

### ■ New Windows 7/ Windows Vista / Windows XP Installation

The following details the installation of the drivers while installing operating system.

1. When you start installing Windows XP, you may encounter a message stating, "Setup could not determine the type of one or more mass storage devices installed in your system". If this is the case, then you are already in the right place and are ready to supply the driver. If this is not the case, then press F6 when prompted at the beginning of Windows setup.
2. Press the "S" key to select "Specify Additional Device".
3. You should be prompted to insert a floppy disk containing the Intel® RAID driver into the A: drive.

Note: For Windows XP, you can use the USB floppy drive only.

For Windows Vista/ Windows 7 you can use CD/ DVD/ USB drive.

### **Important**

*Please follow the instruction below to make an "Intel® RAID Driver" for yourself.*

- Insert the MSI DVD into the DVD-ROM drive.
  - Click the "Browse CD" on the Setup screen.
  - Copy all the contents in `\\Storage\Intel\PCH\i6flpy-x86` or `i6flpy-x64` to a formatted floppy diskette.
  - The driver diskette for Intel® RAID Controller is done.
4. For Windows Vista/ Windows 7:  
During the Operating system installation, after selecting the location to install Vista / Windows 7 click on "Load Driver" button to install a third party SCSI or RAID driver.
  5. When prompted, insert the floppy disk or media (CD/DVD or USB) you created in step 3 and press Enter.
  6. You should be shown a list of available SCSI Adapters.
  7. Select the appropriate Intel RAID controller and press ENTER.
  8. The next screen should confirm that you have selected the Intel® RAID controller. Press ENTER again to continue.
  9. You have successfully installed the Intel® Rapid Storage Technology driver, and Windows setup should continue.
  10. Leave the disk in the floppy drive until the system reboots itself. Windows setup will need to copy the files from the floppy again after the RAID volume is formatted, and Windows setup starts copying files.

**■ Existing Windows Driver Installation**

1. Insert the MSI DVD into the DVD-ROM drive.
2. The DVD will auto-run and the setup screen will appear.
3. Under the Driver tab, click on Intel RAID Drivers.
4. The drivers will be automatically installed.

**■ Confirming Windows Driver Installation**

1. From Windows, open the Control Panel from My Computer followed by the System icon.
2. Choose the Hardware tab, then click the Device Manager tab.
3. Click the "+" in front of the SCSI and RAID Controllers hardware type. The driver Intel(R) SATA RAID Controller should appear.

# Degraded RAID Array

A RAID 1, RAID 5 or RAID 10 volume is reported as degraded when one of its hard drive members fails or is temporarily disconnected, and data mirroring is lost. As a result, the system can only utilize the remaining functional hard drive member. To re-establish data mirroring and restore data redundancy, refer to the procedure below that corresponds to the current situation.

## Missing Hard Drive Member

- 1. Make sure the system is powered off.
- 2. Reconnect the hard drive.
- 3. Reboot the system to Windows; the rebuild will occur automatically.

## Failed Hard Drive Member

- 1. Make sure the system is powered off.
- 2. Replace the failed hard drive with a new one that is of equal or greater capacity.
- 3. Reboot the system to Intel RAID Option ROM by press <Ctrl> and <I> keys simultaneously during the Power-On Self Test (POST).

RAID Volumes

ID	Name	Level	Strip	Size	Status	Bootable
0	Volume0	RAID 1(Mirror)	N/A	XXX.XGB	Degraded	Yes

Physical Disks:

Port	Device Model	Serial #	Size	Type/Status(Vol ID)
1	XXXXXXXXXXXXXX	XXXXXXXXXXXXXX	XXX.XGB	Member Disk (0)
2	XXXXXXXXXXXXXX	XXXXXXXXXXXXXX	XXX.XGB	Member Disk (0)

Press <CTRL-I> to enter Configuration Utility..

- 4. Select the port of the destination disk for rebuilding, and then press ENTER.

[ MAIN MENU ]

1 Create RAID Volume

4 Recovery Volume Options

[ DEGRADED VOLUME DETECTED ]

"Degraded" volume and disk available for rebuilding detected. Selecting a disk initiates a rebuild. Rebuild completes in the operating system.

Select the port of the destination disk for rebuilding (ESC to exit):


Port	Drive	Model	Serial #	Size
1	XXXX-XXXXXXX	XXXXXXXXXXXXXX	XXX.XGB	

[ ↑ ↓ ] - Previous/ Next   [ ENTER ] - Select   [ ESC ] - Exit

[ ↑ ↓ ] - Select   [ ESC ] - Exit   [ ENTER ] - Select Menu



5. Exit Intel RAID Option ROM, and then reboot to Windows system.
6. When prompted to rebuild the RAID volume, click 'Yes'.
7. The Intel Rapid Storage Technology application will be launched. Right-click the new hard drive and select 'Rebuild to this Disk'. The 'Rebuild Wizard' will be launched which will guide you through the process of rebuilding to the new hard drive.



## System Acceleration

Intel® Rapid Storage Technology use a SSD as a cache. Which can store frequently used data without having to use a slow virtual disk or depend on RAM. The SSD cache with the advantages of high-speed read/write and non-volatile memory to accelerate the system performance.

### **Important**

*Check your SSD manufacturer's website, upgrade firmware in order to support Intel® Rapid Storage Technology.*

Intel® Rapid Storage Technology can only work with RAID mode. Even though there is only one hard drive, you must set the SATA Mode to RAID in BIOS. The OS must be installed in the RAID ready disk in order to use the SSD caching.

Follow these steps to enable system acceleration. If Windows has been installed in RAID mode, skip to the step 5.

1. Reboot and enter the BIOS setup.
2. Set the SATA Mode to RAID in BIOS.
3. Install Intel® RAID controller driver. Please refer to the section "Installing Driver".
4. Install Windows operating system.
5. Powered off.
6. Connect the SSD.
7. Reboot the system to Windows.
8. Insert the MSI DVD into the DVD-ROM drive.




9. Click the "STORAGE" on the Setup screen.




10. Click the "Intel RAID Driver" to install Intel® Rapid Storage Technology application.

11. Run Intel® Rapid Storage Technology application.
12. Click "Enable acceleration" under Accelerate.



13. Select the acceleration options.




14. Click OK and reboot the system.

The page refreshes and reports the new acceleration configuration in the Acceleration View.

### **Important**

You can click "More help on this page" or "More help" of the Intel® Rapid Storage Technology application to view more information.




# RST Synchronization


If you are using Maximized mode as the Acceleration mode, the data on the hard disk is not always synchronized with the data in the SSD cache. In some situations, you may want to manually sync the disks for avoiding data loss.

Follow these steps to sync manually.


- 1. Reboot system, during the Power-On Self Test (POST) press, press <Ctrl> and <I> keys simultaneously to enter the Intel Rapid Storage Technology Option ROM.
- 2. Select option 5 “Acceleration Options” and press <Enter> key. The following screen appears.



- 3. Press <S> to synchronize data.



- 4. When prompted, press <Y> to confirm.



- 5. Once synchronization is complete, the status will change to In Sync.